

Routine Cleaning

It is recommended that framing be cleaned every 3 to 6 months maximum using non-alkaline detergent and warm water applied with a soft cloth or sponge. A soft bristle brush or nylon pad should only be used with care where & when necessary.

Abrasive cleaners, solvents or other cleaning agents should not be used.

Rollers

The rollers are maintenance free, however care should be taken to avoid a build up of dirt/dust on the rollers. To ensure this the stainless steel track must be kept free from dirt, debris and any other obstructions to enable the rollers to run freely.

Fixing screw tightness and security are to be checked periodically, all in line with manufacturers instructions.

Handles

The smooth operation of handles, locks and tightness of fixing screws to be periodically checked.

Multi point locking Gear

Multi point locking Gear should be periodically lubricated with light engineering oil and fixing screw tightness and security are to be checked, all in line with manufacturers instructions.

Drainage Slots

Drainage slots are to be kept free from dirt and debris. Loose or missing drainage covers should be replaced.

D
E
FA -
B
C